



Frame Mounting Bracket Kits

FORD			
VEHICLE	UMS-Series <i>Under Bed Mount</i>	Premier-Series	SL-Series <i>24" Head Only</i>
2011-2015 F250/350 "Super Duty" (6 ½' & 8' Boxes)	8551000	8552000	8553000
2011-2015 F450 "Super Duty" (6 ½' & 8' Boxes)	8551005	8552000	8553000
2005-2010 F250/350 "Super Duty" (6 ½' & 8' Boxes)	8551000	8552001 or 8552002	8553001
2008-2010 F450 "Super Duty" (6 ½' & 8' Boxes)	8551005	8552001 or 8552002	8553001
2004-2014 F150 (6 ½' & 8' Boxes)(NOT for 5 ½' box installs)	8551000	8552003 or 8552004	8553002
2001-07 F450/550 "Chassis Cab"	N/A	8552005	Not Recommended
1999-2004 F250/350 "Super Duty" (6 ½' & 8' Boxes)	8551000	8552006	8553003
1992-98 F350 (6 ½' & 8' Boxes)	N/A	8552005	8553003
1997-98 F250 "Heavy Duty" (6 ½' & 8' Boxes)	N/A	8552005	8553003
1997-03 F250 "Light Duty" (6 ½' & 8' Boxes)	N/A	8552009	8553004
1997-2003 F150 (6 ½' & 8' Boxes)	N/A	8552009	8553004
1989-96 F150/250 (6 ½' & 8' Boxes)	N/A	8552005	8553005
2000 & earlier Ranger (6 ½' Boxes)	N/A	N/A	8553006
1973-88 F Series (6 ½' & 8' Boxes)	N/A	8552005	8553003

CHEVROLET/GMC

VEHICLE	UMS-Series <i>Under Bed Mount</i>	Premier-Series	SL-Series <i>24" Head Only</i>
2015 Silverado/Sierra 1500 (6 ½' & 8' Boxes only)	8551007	8552027	8553014
2011-2015 Silverado/Sierra 2500 & 3500 HD (6 ½' box only)	8551002	8552011	8553007
2011-2015 Silverado/Sierra 2500 & 3500 HD (8' box only)	8551003	8552011	8553007
2001-2010 Silverado/Sierra 2500 & 3500 HD (6 ½' & 8' Boxes) (Includes New Body Style)	8551004	8552009 or 8552012	8553004
2007-2014 Silverado & Sierra 1500 (6 ½' and 8' Box) (tube frame)	8551005	8552009 or 8552013	8553004
1999-2007 Silverado & Sierra 1500 / 2500 (6 ½' & 8' Boxes)	8551004	8552009	8553004
2001-07 Silverado/Sierra 1500 HD (6 ½' & 8' Boxes)	8551004	8552009	8553004
1988-2001 3500 (6 ½' and 8' Box)	N/A	8552009	8553009
1988-98 1500 / 2500 (8' Box)	N/A	8552009	8553009
1988-98 1500 / 2500 (6 ½' Box)	N/A	8552009	8553009
1987 & earlier S-10 (6 ½' Box)	N/A	N/A	8553003
1987 & earlier (6 ½' & 8' Boxes)	N/A	8552014	Not Recommended

DODGE

VEHICLE	UMS-Series <i>Under Bed Mount</i>	Premier- Series	SL-Series <i>24" Head Only</i>
2009-2014 Ram 1500 (6 ½' & 8' Boxes) No Air Suspension	N/A	8552022	8553010
2002-2008 Ram 1500 (4x2 & 4x4)(6 ½' & 8' Boxes)(Includes Mega Cab)	8551005	8552015 or 8552016	8553004
2014-2015 Ram 2500 (4x2 & 4x4)(6 ½' & 8' Boxes) (Includes Mega Cab)	N/A	8552025	N/A
2013 Ram 2500 (4x2 & 4x4)(6 ½' & 8' Boxes) (Includes Mega Cab)	8551005	8552015 or 8552023	8553004
2003-2012 Ram 2500 (4x2 & 4x4)(6 ½' & 8' Boxes) (Includes Mega Cab)	8551005	8552015 or 8552016	8553004
1999-2007 Silverado & Sierra 1500 / 2500 (6 ½' & 8' Boxes)	8551004	8552009	8553004
2013-15 Ram 3500 (4x2 & 4x4)(6 ½' & 8' Boxes) (Includes Mega Cab)	8551006	8552026	8553013
2003-2012 RAM 3500 (4x4 only)(6 ½' & 8' Boxes) (Includes Mega Cab)	8551005	8552015 or 8552016	8553004
2003-2012 Ram 3500 (4x2 only)(6 ½' & 8' Boxes) (Includes Mega Cab)	8551005	8552017	8553004
1994-2001 Ram 1500/2500/3500	N/A	8552009	8553003
1994-2002 Ram 2500/3500 (6 ½' & 8' Boxes)	N/A	N/A	8553003
1993 & earlier Ram (6 ½' & 8' Boxes)	N/A	8552014	8553003
2005 Dakota (6 ½' Box)	N/A	8552019	8553003
2003-04 Dakota (6 ½' Box)	N/A	8552005	8553003
2002 & earlier Dakota	N/A	8552009	8553003



CALL TOLL FREE ANYWHERE IN CANADA : 1-888-645-6998

5037-50th Avenue, P.O. Box 130, St. Paul, Alberta T0A 3A0

Office: (780) 645-6998

Fax: (780) 645-6506

Email: info@trailercanada.com

www.trailercanada.com

TOYOTA			
VEHICLE	UMS-Series <i>Under Bed Mount</i>	Premier-Series	SL-Series <i>24" Head Only</i>
2001 & earlier Tacoma	N/A	N/A	8553012
2001-06 Tundra (6 ½' & 8' Boxes)	N/A	8552009	Not Recommended
2007-2014 Tundra (6 ½' & 8' Boxes)	N/A	8552020	N/A
2000 & earlier T100	N/A	8552009	8553012

NISSAN			
VEHICLE	UMS-Series <i>Under Bed Mount</i>	Premier-Series	SL-Series <i>24" Head Only</i>
2004-07 Titan (6 ½' & 8' Boxes)	N/A	8552021	N/A
2008 Titan (8' Box Only)	N/A	8552021	N/A